

MOTION *Heat*

HEATED SKI GLOVES



USER MANUAL

REV1.0

THANK YOU FOR YOUR PURCHASE

Thank you for choosing MOTIONHeat™ battery-operated heated gloves. Your high performance heated gloves have been designed to provide you with warmth where and when you need it, whatever the weather.

Our unique heating system uses soft non-metallic fibers that are extremely efficient in generating heat from a low voltage source. These nonmetallic fiber bundles are sewn into your heated gloves to provide warmth to your hands.

Enjoy, and stay warm!

Power In Motion

176, 200 Barclay Parade S.W.
Calgary, Alberta, T2P 4R5
Canada

Phone: 403-233-8841

email: Info@PowerInMotion.ca

website: www.PowerInMotion.ca

Canadian online shop: ca.itselectric.ca

US online shop: us.itselectric.ca

PACKAGED CONTENTS

MOTIONHeat heated gloves can be custom ordered with various contents, although will typically include:

- One pair of heated gloves
- Two 12v Li-ion batteries
- One 12v 1 amp Dual-battery Charger




USING YOUR HEATED LINERS


STEP 1: CONNECT THE BATTERIES

MOTIONHeat heated gloves can be powered from batteries placed inside the glove pockets. The following diagrams illustrate how to connect your batteries.


1. Open the zipper pocket and extract the connector



2. Connect battery to the connector



3. Insert the battery into the pocket




4. Tuck the wire inside the pocket, zip up the pocket



STEP 2: TURN HEATED GLOVES ON/OFF

To turn the gloves ON, press and hold the power button for 1-2 seconds until the power button illuminates.

To turn the gloves OFF, press and hold the power button for 1-2 seconds until the power button turns off.



PRESS AND HOLD FOR 1-2 SECONDS TO TURN ON/OFF


STEP 3: ADJUST HEAT LEVEL

Click the button to toggle to a different heat setting. MOTIONHeat gloves have three heat settings. Ensure to adjust your heat setting to the desired level after turning on your gloves. The gloves will start in the High heat setting after being turned on.

CLICK BUTTON TO CHANGE SETTING



**LOW SETTING
RUNTIME: 7.25 HRS**



**MEDIUM SETTING
RUNTIME: 3.5 HRS**



**HIGH SETTING
RUNTIME: 2.5 HRS**

TIP!

The battery life will change depending on the heat setting of your heated gloves. After your hands are warmed up, reduce the heat setting to low to extend battery life.


STEP 4: CHARGE BATTERIES

Connect the charger unit to the battery connector and plug the charger into the wall outlet. If your battery is fully discharged, it will take up to 5 – 6 hours to charge both batteries. If you charge only one battery at a time, it will take half of the typical charge time. The light on the charger will be red when the batteries are charging, and green when they are fully charged. The charger is a smart charger, so it will not over charge the batteries. However, it is not a good idea to leave the charger plugged into the battery for weeks or months.


HEATED GLOVE ACCESSORIES

Charge Adapters (12v, 110v, 220v)

The MOTIONHeat gloves can be charged from 12v, 110v, or 220v power sources using the adapters listed below:



12v Lighter Socket Adapter



Chargers for Various Countries

Battery size vs heat setting, temperature, and runtime

Battery Size	12v 3200mAh		
Heat Setting	high	med	low
Runtime (hrs)	2.5	3.25	4.25

MAINTAINING YOUR HEATED GLOVES

Off Season Storage

When winter is over and you no longer need to use your heated gloves, remove the battery from the cuff, fully charge the batteries, and place the batteries in a cool, dry area. It is VERY important to charge the batteries before storing for long periods of time. Failing to charge the batteries before storing can SEVERELY decrease the capacity of the batteries.

Important: Don't Get Wet

The Heating system, including the battery pack, is not designed to be used under water. If the gloves get very wet during use (such as in heavy rain or when outside gloves are soaked- or heavy sweat during sports such as skiing) detach the battery pack and do not use until the glove liners are fully dry. In addition, the battery pack must never be immersed in water, as this will cause electrical faults. Keep all electrical parts dry.

Things That You Should NOT Do:



The heating system has been designed for safe and reliable use. DO NOT replace or interfere with the electrical components in the heated gloves or the battery pack.



It is safe to use the heated gloves to heat other body parts such as chest, back, etc. However, do not fall asleep while using the gloves.



Do not leave the heated gloves ON if they are unattended. When the heated gloves are not in use for long periods of time, or when transporting the heated gloves (e.g. in a bag, backpack, or suitcase), the batteries should be disconnected from the gloves.



As a safety precaution, do not leave the heated gloves turned on near highly flammable materials.

WARNINGS



To reduce the risk of injury, always unplug the charger and remove the battery pack from the heated gloves before performing any maintenance. Never disassemble the heated gloves, battery pack, or charger. Contact PowerInMotion or its dealers for all repairs.



To reduce the risk of personal injury and damage, disconnect and remove the battery pack from the battery pocket before washing. Never immerse your battery pack or charger in liquid or allow liquid to flow inside them.



If the heated gloves do not operate properly with a fully charged battery pack, clean the contacts on the battery pack. If the heated gloves still do not work properly, return the heated gloves, charger, and battery pack to PowerInMotion or its dealers for all repairs.



Do not use the battery pack if it has become wet. Keep batteries away from fire and other heat sources to avoid the risk of explosion. Always keep the battery pack out of reach of children.

WARRANTY AND EXCHANGE

Limited Warranty

MOTIONHeat™ gloves (including battery and charger) is warrantied to the original purchaser only to be free from defects in material and workmanship. Subject to certain exceptions, POWERinMOTION will repair or replace any part on MOTIONHeat™ gloves, which, after examination, is determined by POWERinMOTION to be defective in material or workmanship for period of one (1) year after the date of purchase. Return of heated gloves to a POWERinMOTION dealer's location, freight prepaid and insured- as required. A copy of the proof of purchase should be included with the return product. This warranty does NOT apply to damage that POWERinMOTION determines to be from repairs made or attempted by anyone other than POWERinMOTION personnel, misuse, alterations, abuse, normal wear and tear, accidents, water damage, its component has been altered.

Warranty registration is not necessary to obtain the applicable warranty on POWERinMOTION heated gloves. The purchase date of the product will be used to determine the warranty period if no proof of purchase is provided at the time warranty service is requested.

Exchange

MOTIONHeat™ gloves may be exchanged for a different size within 30 days from the date of purchase provided that the gloves were never used. Customer's exchanged gloves can't have any damage or altered look. No exchanges will be accepted for gloves if these conditions are not met.

Return and Refund

MOTIONHeat™ gloves can be returned and refunded (must be within 30 days) when the following conditions are met:

- Gloves are in new condition and have not been used
- Customer's return glove can't have any damage or altered look to gloves and its components
- Package cardboard tag has not been removed from the glove

Refund will include complete set of glove, shipping cost (if applicable) and tax.

Return shipping cost will be paid by customers